

SUGGESTIONS

- ★ Pipet. tech: press down - go in sample - slow release up + down
- ★ Always put master mix in by adding DNA
 ↳ mix really well
- ★ should have Blank measurement
- ★ make a Negative Control - run it out on gel
 Primer/loading dye mix 22.5 μ L + 2.5 μ L water
 (water instead of DNA)
 should have no bands on gel → if you do → have contamin.
- ★ digest PCR products w/ HaeIII - incubate for an hour

